

Identifying 2010 and 2010A Battery Type

Zonar currently uses two types of batteries, Ni-MH (nickel-metal hydride) and Li-Ion (lithium ion), and two versions of handhelds, 2010 and 2010A.

Ordering and installing the correct battery type in the handhelds will prevent damaging the unit and rendering the handheld useless.

Warning: The **Li-Ion** batteries are **NOT** compatible with the old circuit board and should **NEVER** be installed in the 2010 handheld.

Li-Ion (white batteries) →

2010

Warning: Likewise, the **Ni-MH** batteries are **NOT** compatible with the new circuit board and should **NEVER** be installed in the 2010A handheld.

Ni-MH (green batteries) →

2010A

There are 3 different ways you can find out which handheld is a 2010 or a 2010A.

1. Check the back of the handheld to verify handheld type.

2010 = Ni-MH Battery

The 2010 handheld can be identified by checking the model type and the serial number on the back of the handheld.

Model = 2010
 S/N = **less** than 2 million (2,000,000)

Green Batteries



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation

FCC ID: SEJ-2010HH
 Model: Zonar 2010
 IC: 5266A-2010HH
 S/N 1583049



Protected under U.S. Patent No. 6,671,646

Made in the U.S.A.

2010A = Li-Ion Battery

The 2010A handheld can be identified by checking the model type and the serial number on the back of the handheld.

Model = 2010A
 S/N = **greater** than 2 million (2,000,000)

White Batteries



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation

FCC ID: SEJ-2010HH
 Model: Zonar 2010A
 IC: 5266A-2010HH
 S/N 2002042



Protected under U.S. Patent No. 6,671,646

Made in the U.S.A.

2. If you are not able to visually see the model type and serial numbers (printing faded, sticker pulled off), and there is still enough battery life in the handheld, follow the steps below to view the settings on 2010 or 2010A.

<p>1. Turn on the 2010 or 2010A and scan a driver card.</p>		<p>4. Press the INFO button.</p>	
<p>2. Press any button.</p>		<p>5. Scroll down to SETTING and press the RIGHT button.</p>	
<p>3. Press the RIGHT button.</p>		<p>6. With VERSION highlighted, press the RIGHT button.</p>	



2010 = REV "F" and "H" boards

2010A = REV "J" board

3.

As a last resort, remove the battery cover and note the color of the battery (green or white). In the case where the battery door cannot be opened, please contact Help Desk at (877) 843-3847 or by email at helpdesk@zonarsystems.com for additional instructions.

