



omnitrac

innovation. driven.

Critical Event Video Installation Guide

80-JC584-1 Rev. E

May 2017

80-JC584-1 Rev. E

MAY CONTAIN U.S. AND INTERNATIONAL EXPORT CONTROLLED INFORMATION

Omnitracs, LLC
717 N. Harwood Street, Suite 1300
Dallas, TX 75201 U.S.A.

© 2017 Omnitracs, LLC. All rights reserved.

Omnitracs XRS and Omnitracs are trademarks of Omnitracs, LLC. All other trademarks are the property of their respective owners.

Omnitracs endeavors to ensure that the information in this document is correct and fairly stated, but Omnitracs is not liable for any errors or omissions. Published information may not be up to date, and it is important to confirm current status with Omnitracs.

This technical data may be subject to U.S. and international export, re-export or transfer (export) laws. Diversion contrary to U.S. and international law is strictly prohibited.

80-JC584-1 Rev. E

May 2017

Contents

Overview.....	4
Items Included in the CEV Package.....	4
CEV Camera System Components.....	5
Preparing to Install the CEV Camera System.....	7
Recommended Tools and Supplies.....	7
Downloading and Installing the BlackVue App.....	8
Connecting to the CEV Camera(s).....	9
Using the BlackVue App with Android.....	9
Using the BlackVue App with iOS.....	10
Selecting a Mounting Location.....	11
Finding a Power Source.....	12
Installing the CEV Camera System.....	14
Pairing the Camera(s) with Omnitrac products that support Critical Event Video.....	17
Pairing with an Omnitrac mobile unit.....	17
Pairing with an Omnitrac XRS.....	19
Using Critical Event Video with Omnitrac Critical Event Reporting.....	19
Using Critical Event Video with Omnitrac XRS.....	19
Troubleshooting.....	20
The CEV camera system will not power on.....	20
The CEV camera system will not pair with the mobile device.....	20
RMA.....	21
RMA Instructions.....	21
Regulatory Compliance Information.....	22
Appendix A: Parts List.....	23

Overview

This Guide describes the steps required to properly install the Omnitrac Critical Event Video (CEV) camera system. This camera system is intended for use with the following Omnitrac platforms: IVG, MCP200, MCP110, or XRS Mobile.

Note: MCP110 requires either a Wi-Fi enabled WIB or the MCP110 Wi-Fi Dongle to function properly with the CEV system.

Items Included in the CEV Package

Omnitrac ships the CEV Enclosure assembled and ready to install in a vehicle. The CEV package contains the following:

- 1x - Fully assembled Critical Event Video Enclosure system containing the following:
 - A forward-facing camera
 - A driver-facing camera

NOTE: Depending on the CEV Package ordered from Omnitrac, the CEV package may contain only a forward-facing camera.
- 1x – Power Cable
- 1x – CEV Installation Kit consisting of the following:
 - 3M™ Silane Glass Treatment Wipe
 - Alcohol swab
 - Adhesive P-clamps
 - Zip ties for cable securement

CEV Camera System Components

The Critical Event Video system consists of the Camera Mount Enclosure, one or more camera units and a power cable. The unit can be mounted to the vehicle windshield using the included double-sided adhesive.

NOTE: Depending on the selected kit, the CEV Enclosure may include only a forward-facing camera or both cameras.

The Critical Event Video system uses built in Wi-Fi (802.11b/g/n) to connect to devices running Omnitrac's software applications.

Omnitrac's Critical Event Video functionality supports the following high and low resolution settings:

- High – 704x480 @ 10 FPS
- Low – 352x240 @ 10 FPS



Forward-Facing Camera

The forward-facing camera is intended to be mounted in a road-facing position in order to capture events that occur in front of the vehicle.



Driver-Facing Camera

The driver-facing camera is intended to be mounted in a driver-facing position to capture video of the driver in the event of a critical event. This camera has IR functionality that allows for recording in low-light conditions, such as at dusk or night.

CAUTION: Do not connect or disconnect the Driver Facing Camera while the unit is powered on.



Power Cable

The power cable is used to connect the CEV Enclosure with a vehicle power source. The power cable contains a power (red) and ground (black) wire.

Micro-SD Card



A Micro-SD memory card is installed in the forward-facing camera.

CAUTION: In order to prevent data loss, do not insert or remove the SD Memory card while the Camera is powered on.

Preparing to Install the CEV Camera System

Before beginning installation, ensure you have all the parts and tools required. You will also need to download and install the BlackVue app on a mobile device to live stream the image from the camera during installation. You will also need to predetermine where you want to mount the CEV enclosure and what power source you will connect the CEV camera system to.

Note: There are several steps during the installation. Do not permanently attach the enclosure or route the power cable until you are sure you have a good image and are instructed to do so. Also, once you connect the camera to a power source, do not disconnect it until you complete the installation process. You can move the enclosure and make adjustments without disconnecting it from power.

Recommended Tools and Supplies

- T10 Security Torx Tamper Resistant Screwdriver or long shank bit
- Voltmeter or multimeter
- Mobile device with internet access
- Wire Strippers/Cutters
- Butt Splice Crimping Tool
- 16ga Butt Splices (blue) and/or terminating connectors specific to the make and model of vehicle


Downloading and Installing the BlackVue App

The BlackVue app is used to view a live camera feed from the CEV camera(s). This is critical to ensure a consistent and correct image from the cameras. It is recommended that you use the app throughout the install in order to verify and confirm the position of each camera.


Perform the following to install the BlackVue app:

1. From the Google Play or Apple App store, type BlackVue in the search bar and tap the search button.
2. Select the BlackVue app by pittasoft.

NOTE: Make sure to select the BlackVue app and not the BlackVue Legacy or BlackVue Sport apps.



3. Tap **Install**. On iOS tap **Get** then tap **Install**.



4. Review the permissions being requested and tap **Accept**. Some newer versions of Android may have you accept the permissions when you launch the app.

Connecting to the CEV Camera(s)

While installing the CEV camera system you will need to connect to the camera(s) several times to view a live feed from the camera in order to confirm the camera is getting a good image and to adjust the positioning of the camera.

Note for Omnitrac's XRS Platform: It is recommended that technicians performing the install not use the same Android device that has the XRS app for the vehicle. If technicians must use the BlackVue app on the same device that is used by the driver, the BlackVue app should be uninstalled from the device before releasing the vehicle to the driver.



Using the BlackVue App with Android

To view the camera's live feed through the BlackVue App on an Android device:


1. Launch the BlackVue app on your Android device.
2. Tap **Blackvue Wi-Fi**.
3. Tap the SSID for the CEV camera system you are installing. **Note:** The SSID is listed on the barrel of the forward-facing camera. Be sure to make a note of the SSID. You will need the SSID to pair with the MCP or XRS Mobile.

NOTE: If no camera units are available, ensure Wi-Fi is enabled on both the Android device and the CEV camera system. Verify the white Wi-Fi light  is lit on the end of the forward-facing camera. From the BlackVue C app, tap the refresh icon at the bottom of the screen.

4. Enter the password and tap **OK**.
 - a. The default password for new devices is "omnitrac"
 - b. Customers can create custom passwords for their fleets. Confirm with your company's CEV admin for current passwords.



5. Once the BlackVue app connects to the CEV camera system, tap the camera icon to view the live stream from the forward-facing camera.



6. To switch the view between the forward-facing and driver-facing cameras, if used,


tap the  icon.

Using the BlackVue App with iOS

To view the camera's live feed through the BlackVue App on an iOS device:

1. Open the Wi-Fi settings on your mobile device to see a list of Wi-Fi connections available. The camera's SSID should be in the list, if it is not, refresh the list of connections.
2. Connect to the camera system according to your device's instructions. When asked for a password, enter "omnitrac" as the password.
 - a. The default password for new devices is "omnitrac"
 - b. Customers can create custom passwords for their fleets. Confirm with your company's CEV admin for current passwords.
3. Launch the BlackVue app on your iOS device.
4. Tap **Blackvue Wi-Fi**.

5. Once the BlackVue app connects to the CEV camera system, tap the camera icon to view the live stream from the forward-facing camera.



6. To switch the view between the forward-facing and driver-facing cameras, if used, tap

the  icon.


Selecting a Mounting Location

The CEV Enclosure must be installed in the correct location on the vehicle windshield in order to properly capture video and comply with applicable regulations.

A properly installed CEV Enclosure should meet the following criteria

- Be firmly attached to the Vehicle Windshield
- Not obstruct the view of the driver
- Comply with Federal rules and regulations. See the Regulatory Compliance Information section of this guide for more details.
- The forward-facing camera should have a clear view of the road including the hood of the vehicle. For vehicles that are equipped with hood or fender mounted mirrors, the camera should be positioned to capture both mirrors.
- The driver-facing camera view, if used, should include the vehicle operator's head and a view of the steering wheel in any position.

In order to remain compliant with current regulations, Omnitracs recommends the CEV Enclosure be installed at the top-center of the windshield within 6" from the top of the windshield and out of the windshield wiper swipe patch. For vehicles that have a split-windshield, the CEV Enclosure is best suited for installation on the driver side.



Finding a Power Source

The CEV camera system requires a power source of at least 12.4 volts or higher in order to power up. Once powered, the camera(s) require a minimum of 11.8 volts in order to remain on.

Installers should find an available power connection within the vehicle that can provide power that meets these minimum requirements. This power source should also provide constant power. This means it should not be connected to a power source. If available, installers should look for a power source connected to the low voltage disconnect module. If no low voltage disconnect is available, the power cable that comes with the CEV camera system does have a built in low voltage disconnect that will completely power down the camera if the voltage drops below 11.8 volts in order to prevent the camera from draining the vehicle's battery. Installers should also test the vehicle power connection with a voltmeter to ensure enough power is provided to power the CEV camera(s). Vehicles that have not been running may have batteries that are below 12.4 volts. The CEV camera system will not start up even though other

vehicle accessories are on. If below 12.4 volts, allow the batteries to recharge to a point above 12.4 volts.

Camera continuous current draw is:

- a. Forward-facing only: $\sim .35\text{A}@12\text{V}$
- b. Forward and driver facing: $\sim .42\text{A}@12\text{V}$

Installing the CEV Camera System

Note: Due to the variety of vehicle models and installation requirements, installers are responsible for determining the best method to install the CEV power cable in each vehicle. When determining how and where the cable will be routed, consider how to secure the cable to ensure that cable is not pinched, bent, or subject to excessive rubbing or movement.

1. Connect the power cable's power wire to positive and constant power. Do not connect to ignition voltage.
2. Connect the power cable's ground wire to a ground source. Omnitrac recommends grounding to the frame or chassis.
3. Remove the plug covering the T10 tamper resistant screw holding the CEV enclosure together.

Note: This step only applies for the dual enclosure.

4. Using a T10 Torx tamper resistant screwdriver, remove the front cover of the CEV enclosure.
5. Plug the power cable into the DC in connection on the forward-facing camera. Once powered on, the CEV camera system must maintain constant power. You can make adjustments to the camera while it is powered on.



Plug and T10 Torx TR screw on a dual enclosure

Note: When using a driver-facing camera, connect it to the forward-facing camera before powering on the forward-facing camera. Do not connect or disconnect the driver-facing camera while the forward-facing camera is powered on.

6. Using the BlackVue app, connect to the CEV camera system you are installing. Instructions for using the BlackVue app for connecting to the CEV camera system are in the Connecting to the CEV Camera(s) section.
7. Manually hold the CEV enclosure to the mounting location and confirm the camera(s) can provide a good image. Do not remove the protective film covering the adhesive backing until instructed to in step 12.

Note: The forward-facing camera should have a clear view of the road including the hood of the vehicle. For vehicles that are equipped with hood or fender mounted mirrors, the camera should be positioned to capture both mirrors. The driver-facing camera view, if used, should include the vehicle operator's head and a view of the steering wheel in any position. Some adjustments may be needed to fine tune the image that is captured but at this step you simply want to confirm the camera is capable of showing images from the planned mounting location.

- a. If the selected mounting location will not allow for a good image to be captured by the camera(s), select a new mounting location and repeat step 7.

- b. If the selected mounting location will allow for a good image to be captured by the camera(s), proceed to step 8.




Good Forward-Facing Camera Image




Good Driver-Facing Camera Image

8. From the selected power source, route the length of the power cable to the selected mounting location at the top of the Windshield. Depending on the power source location, it may be necessary to remove the dashboard and pillar covers in order to hide the power cable from view.
9. Thoroughly clean the selected mounting position with glass or windshield cleaner (not provided).
10. Wipe the selected mounting position on the windshield with the included alcohol swab to create a clean mounting surface, removing any residue left from the cleaner.
11. Allow the surface to dry completely. Under normal conditions, it is recommended to wait at least two minutes, but high humidity environments will require waiting longer. Any moisture on the surface will cause poor adhesion.
12. Wipe the surface you just cleaned with the included 3M™ Silane Glass Treatment Wipe thoroughly to seal the windshield and allow for better adhesion. Wait two minutes to allow the sealant to dry.
13. Remove the protective film from the adhesive on the enclosure to expose the adhesive surface.
14. Carefully but firmly press the CEV Enclosure into the selected mounting position on the vehicle windshield and hold for 30 seconds.
15. Make adjustments to the forward-facing camera, if needed.
 - a. Using a T10 Torx tamper resistant screwdriver or bit, loosen the camera bracket screws holding the forward-facing camera.
 - b. Using the live feed from the camera, adjust the camera to achieve a good image.
 - c. Tighten the camera bracket screws to secure the camera. Hand tighten only and be sure to securely tighten the screws.
 - d. Confirm the camera is providing a good image that includes the top of the vehicle hood and both side



mirrors, if available.

16. Make adjustments to the driver-facing camera, if used and needed.
 - a. Using a T10 Torx tamper resistant screwdriver or bit, loosen the camera bracket screws holding the driver-facing camera.
 - b. Using the live feed from the camera, adjust the camera to achieve a good image.
 - c. Tighten the camera bracket screws to secure the camera. Hand tighten only and be sure to securely tighten the screws.
 - d. Confirm the camera is providing a good image that includes the vehicle operator's head and a view of the steering wheel in any position.
17. Disconnect the Wi-Fi connection between your mobile device and the camera. If you connected with the BlackVue app, closing the BlackVue app will disconnect. If you connected your phone to the camera directly through your phone's Wi-Fi settings, you will need to manually disconnect the Wi-Fi connection through those same settings.
18. If you have not done so yet, write down the SSID for the camera before proceeding. This information will be needed when pairing the CEV system with an Omnitracs product that supports CEV.
19. Secure the power cable in the CEV enclosure with slack.
 - a. Disconnect the power cable from the forward-facing camera.
 - b. Route the power cable into the CEV enclosure from top of the enclosure.
 - c. Create a J loop with the power cable inside the enclosure.
 - d. Plug the power cable into the DC in connection on the forward-facing camera.
 - e. Attach a zip tie to the power cable right where it enters the enclosure to secure the J loop and power cable slack in the enclosure.
 - f. Run the power cable through the included grommet then place the grommet in the notch at the top of the enclosure.



20. Reattach the CEV enclosure cover.
 - a. Place the CEV enclosure cover over the CEV enclosure, ensuring the grommet stays in place in the notch.
 - b. Tighten the T10 tamper resistant screw to secure the CEV enclosure
 - c. Replace the plug covering the T10 tamper resistant screw, if a dual enclosure.
21. Stow and secure any excess cable. Usually excess cable can be tied and secured behind the dashboard cover.
22. Please ensure that vehicle batteries are fully charged and that available power to camera will continue to stay above 12.4 volts. DO NOT Disconnect Power to the camera during the pairing and configuration process.

Pairing the Camera(s) with Omnitrac products that support Critical Event Video

Once installation of the CEV Enclosure is complete, installers should pair the CEV camera(s) with an Omnitrac product that supports CEV. This will allow users to retrieve videos from the camera.

Pairing with an Omnitrac mobile unit


Critical Event Video is currently supported on the IVG, MCP200, and MCP110. The MCP110 may require additional hardware to enable wi-fi.

Note: In order to pair a camera with an Omnitrac mobile unit, you **must** have the Critical Event Reporting and Critical Event Video applications enabled in the same operational profile that has the mobile unit. The operational profile is also where you configure the camera. For more information about configuring the camera, including how video is sent back to the Critical Event Reporting application the Critical Event Video Configuration Guide, 80-JC585-1. For help managing operational profiles, please contact your Customer Experience Representative.


1. On the mobile unit, open the diagnostics screen.
2. Depending on your mobile unit, choose Camera Configuration or CameraSelection.
 - a. For the MCP200 and MCP110, tap **Camera Configuration**.




- b. For the IVG, tap the drop down menu in the Diagnostics box and select CameraSelection then tap **Run Diags**.



3. Tap the Camera ID for the camera you want to pair the MCP with. To ensure you do not pair with a nearby camera in another vehicle, verify that you choose the correct SSID for the camera you installed in the same vehicle. The SSID is on the barrel of the camera if you need to check it.
4. Tap **Pair**.



5. If this is the first time you are pairing this camera to this MCP, tap Yes to delete the camera's video files.
6. The pairing process will take up to 5 minutes. A confirmation will display in green text once pairing is complete.




7. Wait 5 minutes after pairing completes for the camera to configure its SD card before attempting to trigger a manual event or test the camera.

Pairing with an Omnitrac XRS

In order to pair a CEV system with Omnitrac XRS, you must have a login to Omnitrac XRS with admin-level privileges and the vehicle you want to pair with must already exist in Omnitrac XRS.

1. Login to Omnitrac XRS
2. Click **Admin**.
3. From the Entities column, click **Vehicles**.
4. Locate the vehicle you want to add a CEV system to and click **Edit Vehicle**.
5. Click **Camera**.
6. Click **Add Camera**.
7. From the Add Camera screen:

- a. Select BlackVue as the Camera Model
- b. Select Camera Hotspot as the Connection Type
- c. Enter the SSID for the CEV system you want to pair with.
- d. Enter the password for your CEV System



- i. The default password for new devices is "omnitrac"
 - ii. Customers can create custom passwords for their fleets. Confirm with your company's CEV admin for current passwords.
- e. Click **OK**.
8. If you have additional CEV systems to pair to a vehicle, repeat steps 6 and 7.
 9. Click **Save**.

Using Critical Event Video with Omnitrac Critical Event Reporting

For information on setting up the CEV Enclosure with Omnitrac Critical Event Reporting, see 80-JC585-1, Critical Event Video Configuration Guide.

Using Critical Event Video with Omnitrac XRS

For information on setting up the CEV Enclosure with XRS Mobile, log into the XRS host website, select Help Knowledge Base from the main menu, and search for "Critical Event Video."

Troubleshooting

The CEV camera system will not power on

The CEV camera system requires a power source of at least 12.4 volts or higher in order to power up. Once powered, the camera(s) require a minimum of 11.8 volts in order to remain on.

Ensure the power supply you connected to is providing at least 12.4 volts of continuous power and not an ignition source. Vehicles that have not been running may have batteries that are below 12.4 volts. The CEV camera system will not start up even though other vehicle accessories are on. If below 12.4 volts, allow the batteries to recharge to a point above 12.4 volts.

Ensure all power connections are tightly secured. Check the power cable's connection to the vehicle power source and ensure the power cable plus is snugly secure in the camera's DC IN connection.

Ensure the vehicle power source is providing continuous power. Once connected to power, the CEV camera system needs to maintain continuous power until the installation is complete.

The CEV camera system will not pair with the mobile device

The CEV camera system can only be paired with one device at a time and also must be properly configured in either the operational profile on the Customer Portal (IVG and MCP users) or on the XRS Portal (XRS users).

First, check to ensure the mobile device you used to livestream the camera and verify the picture during installation is not still connected to the CEV camera system. If it is still connected, disconnect it through your mobile device's Wi-Fi settings and choose the option to "Forget Network" to ensure it does not reconnect automatically. Then attempt to pair again.

If that does not fix the issue, work with your system administrator to ensure the Operational Profile or XRS Portal are properly configured for the CEV Camera system to associate with the vehicle you are installing it in. Configuring the CEV Camera system and operational profile for IVG and MCP users is covered in the Critical Event Video Configuration Guide, 80-JC585-1. For help setting up the CEV camera system in the XRS Portal, see the XRS knowledgebase.

Installation Videos

Scan the QR codes below with a QR code or barcode scanner on your mobile device to launch a video detailing the installation process. Omnitrac's recommends viewing these videos while connected to Wi-Fi. Standard mobile phone carrier and data usage charges may apply.



IVG



XRS



MCP200 or MCP110

RMA

When returning a defective camera, only return the camera and the SD card. Keep the CEV enclosure and the brackets that secure the camera in the enclosure and any cabling. Only the serialized camera(s) are returnable. Only request an RMA for the defective camera. You will need the serial number of the defective camera(s) when requesting an RMA.

RMA Instructions

If your CEV system is not functioning correctly, please attempt to find a solution in the troubleshooting section first. If that does not work, please contact your Customer Experience Representative or Omnitrac's Technical Support (800-541-7490 or www-ocus@omnitrac.com).

If instructed to return a defective unit, follow these instructions to initiate an RMA:

1. Log in to Omnitrac's Customer Portal at <https://customer.omnitrac.com>.
2. Click the **Returns** icon.
3. Click **Continue** under **Initiate RMA**.
4. After you are issued an RMA number, a replacement will be shipped.
5. Return the defective device within 30 days.

Regulatory Compliance Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

All objects mounted to the vehicle windshield must be mounted in a manner that limits the impact to driver visibility and complies with FMCSA regulations.

Do not locate the CEV unit or associated hardware where it obstructs the driver's field of vision, distracts the driver from the driving task, or interferes with the driver's operation of controls or instruments.

FMCSA regulation 393.60 (e) and (2) describe the allowed locations to mount objects to the vehicle windshield.

For additional information about FMCSA regulation 393, see <https://www.fmcsa.dot.gov/regulations/title49/section/393.60>.

FMCSA Regulation 393.60 (e) and (2) PARTS AND ACCESSORIES NECESSARY FOR SAFE OPERATION

§ 393.60: Glazing in specified openings.

(e) Prohibition on obstructions to the driver's field of view —(1) Devices mounted at the top of the windshield. Antennas, transponders, and similar devices must not be mounted more than 152 mm (6 inches) below the upper edge of the windshield. These devices must be located outside the area swept by the windshield wipers, and outside the driver's sight lines to the road and highway signs and signals.

(2) Decals and stickers mounted on the windshield. Commercial Vehicle Safety Alliance (CVSA) inspection decals, and stickers and/or decals required under Federal or State laws may be placed at the bottom or sides of the windshield provided such decals or stickers do not extend more than 115 mm (4 1/2 inches) from the bottom of the windshield and are located outside the area swept by the windshield wipers, and outside the driver's sight lines to the road and highway signs or signals.

Appendix A: Parts List

The following parts list can be referenced in order to order replacement parts from Omnitrac. To order replacement parts for the Critical Event Video Enclosure, visit the Customer Portal at <https://customer.omnitrac.com> or contact your Customer Experience Representative.

<i>System Component</i>	<i>MCN</i>
Critical Event Video System Master Packs	
M-Pack, Critical Event Video System, Two Camera Enclosure	MK10-JC584-1
M-Pack, Critical Event Video System, Forward Camera, Individual Camera Enclosure, CEV	MK10-JC602-1
M-Pack, Critical Event Video System, Driver Camera, Individual Camera Enclosure, CEV	MK10-JC603-1
Critical Event Video Installation Kits	
Kit, Install, CEVS	65-JC588-1
Critical Event Video System Miscellaneous Components	
Camera, Forward, 64MB, Serialized, CEVS	CA90-JC584-1
Camera, Driver, IR, Serialized, CEVS	CA90-JC584-2
Assembly, Critical Event Video System, Two Camera Enclosure	55-JC584-1
Assembly, Critical Event Video, Forward Camera, Individual Camera Enclosure	55-JC602-1
Assembly, Critical Event Video, Driver Camera, Individual Camera Enclosure	55-JC603-1
Cable Assembly, Batt_V, Gnd, CEVS	45-JC584-A188
Kit, Tape, VHB, 10 Pack, FWD Camera, Individual Camera Enclosure, CEV	65-JC638-1
Kit, Tape, VHB, 10 Pack, Driver Camera, Individual Camera Enclosure, CEV	65-JC639-1
Critical Event Video System Documentation	
Critical Event Video Getting Started Guide	80-JC586-1
Critical Event Video Configuration Guide	80-JC585-1